


## Tools needed

**2x**  
Security Screw  
(by EOS)



## IMPORTANT

**5° - 15°**

If the roof pitch is less than 5°, a wedge (by others) must be built under product.  
Max roof pitch is 15°.

— BY EOS  
— BY OTHERS

Brackets & Screws  
Arris Rails  
Roof Membrane  
Wedge (if pitch is below 5°)

## Step by Step Guide

- ① Build upstand to dimensions provided (See relevant technical drawing).
- ② If required, fix arris rail to outside of upstand (by others).
- ③ Weatherproof the sides of upstand (by others). Weathering material should not be applied to top of upstand.
- ④ Stick weathering tape (by EOS) to upstand as shown.
- ⑤ Place lid on upstand and fix with screws provided (security screws should be fitted on opposite sides)

